

**Your personal one-time password token
for enhanced Internet security**



When using the one-time password token for the first time, you need to change the initial PIN as follows:

1. Switch on the one-time password token with the **ON** button. **ENTR PIN** is shown.
2. Enter your six-digit initial PIN, which you have received via separate mail. Once you have correctly entered the initial PIN, **NEW PIN** is automatically displayed.

If the initial PIN is not entered correctly, **CHALLNG?** appears. Switch off the one-time password token with the **ON** button. Begin again with step one.

Then enter your correct six-digit PIN. **AGAIN** is automatically displayed. Now confirm the PIN entered. If the entry was correct, **SUCCESS** is displayed, followed by **CHALLNG?**.

3. The initial PIN has been changed and your one-time password token is ready to be used.